

# USER MANUAL

## JUVENTUS WIRED CONTROLLER FOR PS4

### Product Introduction:

Juventus PS4 Wired Gamepad is a new patent design which compatible with PS4, PS4 Slim, PS4 Pro consoles.

Gamepad can be upgraded on PC via USB cable, if new system of PS4 console released

### Product Features:

<b>Standard Buttons:</b>	PS, Share, Option, ↑, ↓, ←, →, X, ○, □, △, L1, L2, L3, R1, R2, R3, VRL, VRR, RESET.
<b>Software Support:</b>	Support with all versions of PS4.
<b>Compatible:</b>	Full compatible with PS4
<b>Sensor:</b>	Without Six axis sensor function
<b>Vibration:</b>	Double Vibration
<b>Touchpad:</b>	Without touch function, only with button function
<b>Speaker:</b>	Without speaker function
<b>Mic/Headset:</b>	3.5mm TRRS stereophonic hole, support mic and headset.
<b>Connect Method:</b>	USB Cable
<b>Cable Length:</b>	3 Meters

### Firmware Update Instruction:

The controller can still work well with PS4 console under some normal updates, but some emergency updates, it will need a driver to update controller. The latest driver can be downloaded from our website:

[www.gametekk.it/accessori-juventus/](http://www.gametekk.it/accessori-juventus/)

Please do firmware update via a windows PC as follow steps

Step 1

Press "PS" button and hold it



Step 2

Plug controller into PC



Step 3

Select "wire" and press "Update" button to start updating



Step 4

The update is successfully when "PASS" released. If failed in updating, just try it again.

